

4

Fuel Air and Actual Cycles

Contents

4.1	Introduction	4.2
4.2	Fuel-Air Cycle.....	4.2
4.3	Variable Specific Heats.....	4.3
4.4	Change of Internal energy and enthalpy during a process with variable specific heats.....	4.4
4.5	Isentropic expansion with variable specific heats.....	4.5
4.6	Effect of variable specific heats on air standard efficiency of Otto and diesel cycle	4.6
4.7	Dissociation	4.7
4.8	Effect of operating variables	4.9
4.9	Comparison of air standard and actual cycles	4.13
4.10	Deviation of Actual cycle from Fuel-Air cycle.....	4.13

4.1 Introduction

- ▶ The air cycle approximation of air standard theory has highly simplified assumptions. The air standard theory gives an estimate of engine performance which is much greater than the actual performance. For example the actual indicated thermal efficiency of a petrol engine of, say compression ratio 7:1, is of the order of 30% whereas the air standard efficiency is of the order of 54%.
- ▶ This large divergence is partly due to non-instantaneous burning and valve operation, incomplete combustion, etc. But the main reason of divergence is the oversimplification in using the values of the properties of the working fluid for cycle analysis.
- ▶ In the air cycle analysis it was assumed that the working fluid is nothing but air and this air was a perfect gas and had constant specific heats.
- ▶ In actual engine the working fluid is not air but a mixture of air, fuel and residual gases. Furthermore, the specific heats of the working fluid are not constant but increase as temperature rises, and finally, the products of combustion are subjected to dissociation at high temperature.

4.2 Fuel-Air Cycle

4.2.1 Factors considered for Fuel-Air cycle calculations

- ▶ The following factors are taken into consideration while making fuel-air cycle calculations:
 - **The actual composition of the cylinder gases:** The cylinder gases contains fuel, air, water vapour and residual gas. The fuel-air ratio changes during the operation of the engine which changes the relative amounts of CO₂, water vapour, etc.
 - **The variation in the specific heat with temperature:** Specific heats increase with temperature except for mono-atomic gases. Therefore, the value of γ also changes with temperature.
 - **The effect of dissociation:** The fuel and air do not completely combine chemically at high temperatures (above 1600 K) and this leads to the presence of CO, H₂, H and O₂ at equilibrium conditions.
 - **The variation in the number of molecules:** The number of molecules present after combustion depends upon fuel-air ratio and upon the pressure and temperature after the combustion.

4.2.2 Assumptions made for Fuel-Air cycle analysis

- ▶ There is no chemical change in either fuel or air prior to combustion.
- ▶ Subsequent to combustion, the charge is always in chemical equilibrium.
- ▶ There is no heat exchange between the gases and the cylinder walls in any process, i.e. they are adiabatic. Also the compression and expansion processes are frictionless.
- ▶ In case of reciprocating engines it is assumed that fluid motion can be ignored inside the cylinder.
- ▶ With particular reference to constant- volume fuel-air cycle, it is also assumed that
- ▶ The fuel is completely vaporized and perfectly mixed with the air, and
- ▶ The burning takes place instantaneously at top dead centre (at constant volume).

4.2.3 Importance of Fuel-Air cycle

- ▶ The air-standard cycle analysis shows the general effect of only compression ratio on engine efficiency whereas the fuel-air cycle analysis gives the effect of variation of fuel-air ratio, inlet pressure and temperature on the engine performance. It will be noticed that compression ratio and fuel-air ratio are very important parameters of the engine while inlet conditions are not so important.
- ▶ The actual efficiency of a good engine is about 85 per cent of the estimated fuel-air cycle efficiency. A good estimate of the power to be expected from the actual engine can be made from fuel-air cycle analysis. Also, peak pressures and exhaust temperatures which affect the engine structure and design

can be estimated reasonably close to an actual engine. Thus the effect of many variables on the performance of an engine can be understood better by fuel-air cycle analysis.

4.3 Variable Specific Heats

- ▶ All gases, except mono-atomic gases, show an increase in specific heat with temperature. The increase in specific heat does not follow any particular law. However, over the temperature range generally encountered for gases in heat engines (300 K to 2000 K) the specific heat curve is nearly a straight line which may be approximately expressed in the form

$$\begin{aligned} C_p &= a_1 + K_1 T \\ C_v &= b_1 + K_1 T \end{aligned} \quad \text{Eq. (4.1)}$$

where a_1, b_1 and K_1 are constants. Now,

$$R = C_p - C_v = a_1 - b_1$$

where R is the characteristic gas constant.

- ▶ Above 1500 K the specific heat increases much more rapidly and may be expressed in the form

$$\begin{aligned} C_p &= a_1 + K_1 T + K_2 T^2 \\ C_v &= b_1 + K_1 T + K_2 T^2 \end{aligned}$$

- ▶ In above equations if the term T^2 is neglected it becomes same as Eq. (4.9). Many expressions are available even upto sixth order of T (i.e. T^6) for the calculation of C_p and C_v .
- ▶ The physical explanation for increase in specific heat is that as the temperature is raised, larger fractions of the heat would be required to produce motion of the atoms within the molecules. Since temperature is the result of motion of the molecules, as a whole, the energy which goes into moving the atoms does not contribute to proportional temperature rise. Hence, more heat is required to raise the temperature of unit mass through one degree at higher levels. This heat by definition is the specific heat. The values for C_p and C_v for air are usually taken as

$$C_p = 1.005 \text{ kJ/kg K}, \quad C_v = 0.717 \text{ kJ/kg K} \quad \text{at 300 K}$$

$$C_p = 1.345 \text{ kJ/kg K}, \quad C_v = 1.057 \text{ kJ/kg K} \quad \text{at 2000 K}$$




Fig.4.1 – Loss of power due to variation of specific heat

- ▶ Since the difference between C_p and C_v is constant, the value of γ decreases with increase in temperature. Thus, if the variation of specific heats is taken into account during the compression

stroke, the final temperature and pressure would be lower than if constant values of specific heat are used. This point is illustrated in Fig.4.1.

- ▶ With variable specific heats, the temperature at the end of compression will be 2', instead of 2. The magnitude of drop in temperature is proportional to the drop in the value of ratio of specific heats. For the process 1→2, with constant specific heats

$$T_2 = T_1 \left(\frac{v_1}{v_2} \right)^{\gamma-1}$$

with variable specific heats,

$$T_{2'} = T_1 \left(\frac{v_1}{v_{2'}} \right)^{k-1}$$

where $k = \frac{C_p}{C_v}$. Note that $v_{2'} = v_2$ and $v_1/v_2 = v_1/v_{2'} = r$.

- ▶ For given values of T_1 , p_1 and r , the magnitude of T_2 depends on k . Constant volume combustion, from point 2' will give a temperature $T_{3'}$ instead of T_3 . This is due to the fact that the rise in the value of C_v because of variable specific heat, which reduces the temperature as already explained.
- ▶ The process, 2'-3' is heat addition with the variation in specific heat. From 3', if expansion takes place at constant specific heats, this would result in the process 3'-4'' whereas actual expansion due to variable specific heat will result in 3'-4' and 4' is higher than 4''. The magnitude in the difference between 4' and 4'' is proportional to the reduction in the value of γ .
- ▶ Consider the process 3'-4''

$$T_{4''} = T_{3'} \left(\frac{v_{3'}}{v_{4''}} \right)^{k-1}$$

For the process 3'-4'

$$T_{4'} = T_{3'} \left(\frac{v_{3'}}{v_{4'}} \right)^{\gamma-1}$$

- ▶ Reduction in the value of k due to variable specific heat results in increase of temperature from $T_{4''}$ to $T_{4'}$.

4.4 Change of Internal energy and enthalpy during a process with variable specific heats

4.4.1 Change of Internal energy

- ▶ The small change in internal energy of a unit mass of a gas for small change in temperature (dT) is given by:

$$\begin{aligned} du &= C_v dT \\ \therefore u_2 - u_1 &= \int_{T_1}^{T_2} C_v dT \\ &= \int_{T_1}^{T_2} (b + KT) dT \\ &= \left[bT + K \frac{T^2}{2} \right]_{T_1}^{T_2} = b(T_2 - T_1) + \frac{K}{2} (T_2^2 - T_1^2) \\ &= (T_2 - T_1) \left[b + K \frac{(T_2 + T_1)}{2} \right] \\ &= (T_2 - T_1) (b + KT_m) \quad \text{where, } T_m = \frac{T_1 + T_2}{2} \end{aligned}$$

► Now,

$$C_{vm} = b + KT_m \quad (C_{vm} \text{ mean specific heat at constant volume})$$

$$\therefore u_2 - u_1 = C_{vm}(T_2 - T_1) \quad \text{Eq. (4.2)}$$

4.4.2 Change of Enthalpy

► The small change in internal energy of a unit mass of a gas for small change in temperature (dT) is given by:

$$\begin{aligned} dh &= C_p dT \\ \therefore h_2 - h_1 &= \int_{T_1}^{T_2} C_p dT \\ &= \int_{T_1}^{T_2} (a + KT) dT \\ &= \left[aT + K \frac{T^2}{2} \right]_{T_1}^{T_2} = a(T_2 - T_1) + \frac{K}{2}(T_2^2 - T_1^2) \\ &= (T_2 - T_1) \left[a + K \frac{(T_2 + T_1)}{2} \right] \\ &= (T_2 - T_1)(a + KT_m) \quad \text{where, } T_m = \frac{T_1 + T_2}{2} \end{aligned}$$

► Now,

$$C_{pm} = a + KT_m \quad (C_{pm} \text{ mean specific heat at constant pressure})$$

$$\therefore h_2 - h_1 = C_{pm}(T_2 - T_1) \quad \text{Eq. (4.3)}$$

4.5 Isentropic expansion with variable specific heats

► Consider one kg of air, the heat transfer to a system using first law can be written as

$$\begin{aligned} dQ &= du + dW \\ dQ &= C_v dT + p dv \end{aligned}$$

► For isentropic process, $dQ = 0$

$$\begin{aligned} \therefore C_v dT + p dv &= 0 \\ \therefore C_v \frac{dT}{T} + \frac{p}{T} dv &= 0 \\ \therefore C_v \frac{dT}{T} + R \frac{dv}{v} &= 0 \quad (\because pv = RT) \end{aligned}$$

► Putting the values of R and C_v in the above equation, we get

$$\therefore (b + KT) \frac{dT}{T} + (a - b) \frac{dv}{v} = 0$$

► Integrating both sides we get

$$\begin{aligned} \therefore \int (b + KT) \frac{dT}{T} + \int (a - b) \frac{dv}{v} &= \text{constant} \\ \therefore \int b \frac{dT}{T} + K \int dT + (a - b) \int \frac{dv}{v} &= \text{constant} \\ \therefore b \log_e T + KT + (a - b) \log_e v &= \text{constant} \\ \therefore \log_e T^b + \log_e e^{KT} + \log_e v^{(a-b)} &= \text{constant} \\ \therefore T^b e^{KT} v^{(a-b)} &= \text{constant} \\ \therefore T e^{\frac{K}{b} T} v^{\frac{(a-b)}{b}} &= \text{constant} \end{aligned}$$

$$\therefore \frac{T}{v} e^{\frac{K_T}{b} T} v^{\frac{a}{b}} = \text{constant} \quad \text{Eq. (4.4)}$$

$$pv = RT \quad \Rightarrow \quad \frac{T}{v} = \frac{p}{R} = \frac{p}{a-b}$$

- ▶ Inserting the value of above equation in Eq. (4.9).

$$\therefore \frac{p}{a-b} e^{\frac{K_T}{b} T} v^{\frac{a}{b}} = \text{constant}$$

$$\therefore pv^{\frac{a}{b}} e^{\frac{KT}{b}} = \text{constant} \quad \text{Eq. (4.5)}$$

4.6 Effect of variable specific heats on air standard efficiency of Otto and diesel cycle

4.6.1 Otto cycle

- ▶ The air standard efficiency of Otto cycle is given by

$$\eta = 1 - \frac{1}{r^{\gamma-1}}$$

We have,

$$C_p - C_v = R$$

$$\therefore \frac{C_p}{C_v} - 1 = \frac{R}{C_v}$$

$$\therefore \gamma - 1 = \frac{R}{C_v} \quad \left(\because \frac{C_p}{C_v} = \gamma \right) \quad \text{Eq. (4.6)}$$

- ▶ Putting Eq. (4.9) in the efficiency equation

$$\therefore \eta = 1 - \frac{1}{r^{\frac{R}{C_v}}} = 1 - r^{-\frac{R}{C_v}}$$

$$\therefore 1 - \eta = (r)^{-\frac{R}{C_v}}$$

- ▶ Taking log on both sides, we have

$$\therefore \log_e(1 - \eta) = -\frac{R}{C_v} \log_e(r)$$

- ▶ Differentiating the above equation, we have

$$\therefore -\frac{1}{1 - \eta} \frac{d\eta}{dC_v} = -R \log_e r \left(-\frac{1}{C_v^2} \right)$$

$$\therefore \frac{d\eta}{1 - \eta} = -\frac{R}{C_v} \cdot \log_e r \cdot \frac{dC_v}{C_v}$$

$$\therefore \frac{d\eta}{\eta} = -\frac{1 - \eta}{\eta} \cdot (\gamma - 1) \cdot \log_e r \cdot \frac{dC_v}{C_v} \quad \text{Eq. (4.7)}$$

- ▶ Negative sign indicates the decrease in efficiency with increase in C_v .
- ▶ The Eq. (4.9) gives the percentage variation in air standard efficiency of Otto cycle on account of percentage variation in C_v .

4.6.2 Diesel Cycle

- ▶ The air standard efficiency of diesel cycle is given by

$$\eta = 1 - \frac{1}{(r)^{\gamma-1}} \left[\frac{\rho^\gamma - 1}{\gamma(\rho - 1)} \right]$$

- ▶ Taking log on both sides, we get

$$\therefore \log(1 - \eta) = \log(\rho^\gamma - 1) - \log(r)^{\gamma-1} - \log \gamma - \log(\rho - 1)$$

$$\therefore \log(1 - \eta) = \log(\rho^\gamma - 1) - (\gamma - 1) \log r - \log \gamma - \log(\rho - 1)$$

- ▶ Differentiating the above equation with respect to γ

$$\begin{aligned} \therefore -\frac{1}{1-\eta} \cdot \frac{d\eta}{d\gamma} &= \frac{1}{\rho^\gamma - 1} \cdot \rho^\gamma \log_e \rho - \log_e r - \frac{1}{\gamma} \\ \therefore \frac{d\eta}{d\gamma} &= (1 - \eta) \left[\log_e r - \frac{\rho^\gamma \log_e \rho}{\rho^\gamma - 1} + \frac{1}{\gamma} \right] \end{aligned}$$

- ▶ Multiplying the above equation by $d\gamma/\eta$

$$\therefore \frac{d\eta}{\eta} = \left(\frac{1 - \eta}{\eta} \right) \left[\log_e r - \frac{\rho^\gamma \log_e \rho}{\rho^\gamma - 1} + \frac{1}{\gamma} \right] \cdot d\gamma \quad \text{Eq. (4.8)}$$

- ▶ Eq. (4.6) is $\gamma - 1 = \frac{R}{C_v}$, differentiating this equation with respect to C_v


$$\begin{aligned} \therefore \frac{d\gamma}{dC_v} &= -\frac{R}{C_v^2} \Rightarrow d\gamma = -\frac{R}{C_v} \cdot \frac{dC_v}{C_v} \\ \therefore d\gamma &= -(\gamma - 1) \cdot \frac{dC_v}{C_v} \quad \text{Eq. (4.9)} \end{aligned}$$

- ▶ Inserting the value of Eq. (4.9) into Eq. (4.8), we get


$$\therefore \frac{d\eta}{\eta} = -\frac{1 - \eta}{\eta} \cdot (\gamma - 1) \left[\log_e r - \frac{\rho^\gamma \log_e \rho}{\rho^\gamma - 1} + \frac{1}{\gamma} \right] \cdot \frac{dC_v}{C_v}$$

4.7 Dissociation

- ▶ Dissociation process can be considered as the disintegration of combustion products at high temperature.
- ▶ Dissociation can also be looked as the reverse process to combustion. During dissociation the heat is absorbed whereas during combustion the heat is liberated.
- ▶ In IC engines, mainly dissociation of CO_2 into CO and O_2 occurs, whereas there is a very little dissociation of H_2O .
- ▶ The dissociation of CO_2 into CO and O_2 starts commencing around 1000°C and the reaction equation can be written as



- ▶ Similarly, the dissociation of H_2O occurs at temperatures above 1300°C and written as



- ▶ The presence of CO and O_2 in the gases tends to prevent dissociation of CO_2 ; this is noticeable in a rich fuel mixture, which, by producing more CO , suppresses dissociation of CO_2 .
- ▶ On the other hand, there is no dissociation in burnt gases of a lean fuel-air mixture. This is mainly due to the fact that temperature produced is too low for this phenomenon to occur.
- ▶ Hence, the maximum extent of dissociation occurs in the burnt gases of the chemically correct fuel-air mixture when the temperatures are expected to be high but decreases with the leaner and richer mixtures.
- ▶ In case of internal combustion engines heat transfer to the cooling medium causes a reduction in the maximum temperature and pressure. As the temperature falls during the expansion stroke the

separated constituents recombine; the heat absorbed during dissociation is thus again released, but it is too late in the stroke to recover entirely the lost power. A portion of this heat is carried away by the exhaust gases.




Fig.4.2 – Effect of dissociation on temperature

- ▶ Fig.4.2 shows a typical curve that indicates the reduction in the temperature of the exhaust gas mixtures due to dissociation with respect to air-fuel ratio. With no dissociation maximum temperature is attained at chemically correct air-fuel ratio.
- ▶ With dissociation maximum temperature is obtained when mixture is slightly rich. Dissociation reduces the maximum temperature by about 300 °C even at the chemically correct air-fuel ratio. In the Fig.4.2, lean mixtures and rich mixtures are marked clearly.




Fig.4.3 – Effect of dissociation on power

- ▶ The effect of dissociation on output power is shown in Fig.4.3 for a typical four-stroke spark-ignition engine operating at constant speed. If there is no dissociation the brake power output is maximum when the mixture ratio is stoichiometric.
- ▶ The shaded area between the brake power graphs shows the loss of power due to dissociation. When the mixture is quite lean there is no dissociation. As the air-fuel ratio decreases i.e., as the mixture becomes rich the maximum temperature raises and dissociation commences.

- ▶ The maximum dissociation occurs at chemically correct mixture strength. As the mixture becomes richer, dissociation effect tends to decline due to incomplete combustion.




Fig.4.4 – Effect of dissociation shown on a p-V diagram

- ▶ Dissociation effects are not so pronounced in a CI engine as in an SI engine. This is mainly due to
 - the presence of a heterogeneous mixture and
 - excess air to ensure complete combustion
 Both these factors tend to reduce the peak gas temperature attained in the CI engine.
- ▶ Fig.4.4 shows the effect of dissociation on p-V diagram of Otto cycle. Because of lower maximum temperature due to dissociation the maximum pressure is also reduced and the state after combustion will be represented by 3' instead of 3. If there was no reassociation due to fall of temperature during expansion the expansion process would be represented by 3'-4'' but due to reassociation the expansion follows the path 3'-4'.
- ▶ By comparing with the ideal expansion 3-4, it is observed that the effect of dissociation is to lower the temperature and consequently the pressure at the beginning of the expansion stroke. This causes a loss of power and also efficiency. Though during recombining the heat is given back it is too late to contribute a convincing positive increase in the output of the engine.

4.8 Effect of operating variables

- ▶ The effect of common engine operating variables on the pressure and temperature within the engine cylinder is better understood by fuel-air cycle analysis. The details are discussed in this section.

4.8.1 Compression Ratio

- ▶ The fuel-air cycle efficiency increases with the compression ratio in the same manner as the air-standard cycle efficiency, principally for the same reason (more scope of expansion work. This is shown in Fig.4.5.
- ▶ The variation of indicated thermal efficiency with respect to the equivalence ratio for various compression ratios is given in fig 2.6. The equivalence ratio, ϕ , is defined as ratio of actual fuel-air ratio to chemically correct fuel-air ratio on mass basis.




Fig.4.5 – Effect of compression ratio and mixture strength on efficiency




Fig.4.6 – Effect of mixture strength on thermal efficiency for various compression ratios

- ▶ The maximum pressure and temperature increase with compression ratio since the temperature, T_2 , and pressure, p_2 , at the end of compression are higher. However, it can be noted from the experimental results that the ratio of fuel-air cycle efficiency to air-standard efficiency is independent of the compression ratio for given equivalence ratio for the constant volume fuel-air cycle.

4.8.2 Fuel Air ratio

4.8.2.1 Efficiency

- ▶ As the mixture is made lean (less fuel) the temperature rise due to combustion will be lowered as a result of reduced energy input per unit mass of mixture. This will result in lower specific heat.
- ▶ Further, it will lower the losses due to dissociation and variation in specific heat. The efficiency is therefore, higher and, in fact, approaches the air-cycle efficiency as the fuel-air ratio is reduced as shown in Fig.4.7.




Fig.4.7 – Effect of mixture strength on thermal efficiency

4.8.2.2 Maximum Power

- ▶ Fig.4.8 gives the cycle power as affected by fuel-air ratio. By air-standard theory maximum power is at chemically correct mixture, but by fuel-air theory maximum power is when the mixture is about 10% rich. As the mixture becomes richer the efficiency falls rapidly.




Fig.4.8 – Effect of fuel-air ratio on power

- ▶ This is because in addition to higher specific heats and chemical equilibrium losses, there is insufficient air which will result in formation of CO and H₂ in combustibles, which represents a direct wastage of fuel.

4.8.2.3 Maximum temperature

- ▶ At a given compression ratio the temperature after combustion reaches a maximum when the mixture is slightly rich, i.e., around 6% or so ($F/A = 0.072$ or $A/F = 14:1$) as shown in Fig.4.9.
- ▶ At chemically correct ratio there is still some oxygen present at the point 3 because of chemical equilibrium effects a rich mixture will cause more fuel to combine with oxygen at that point thereby raising the temperature T_3 . However, at richer mixtures increased formation of CO counters this effect.

4.8.2.4 Maximum Pressure

- ▶ The pressure of a gas in a given space depends upon its temperature and the number of molecules. The curve of p_3 , therefore follows T_3 , but because of the increasing number of molecules p_3 does not start to decrease until the mixture is somewhat richer than that for maximum T_3 (at $F/A = 0.083$ or $A/F = 12:1$), i.e. about 20 per cent rich (Fig.4.9).




Fig.4.9 – Effect of equivalence ratio on T_3 and P_3

4.8.2.5 Exhaust Temperature

- ▶ The exhaust gas temperature, T_4 is maximum at the chemically correct mixture as shown in Fig.4.10. At this point there is reassociation as the temperature decrease so heat will be released these heat cannot be used in engine cylinder so the exhaust gases carry these heat with them and it result in higher exhaust temperature.
- ▶ At lean mixtures, because of less fuel, T_3 is less and hence T_4 is less. At rich mixtures less sensible energy is developed and hence T_4 is less. That is, T_4 varies with fuel-air ratio in the same manner as T_3 except that maximum T_4 is at the chemically correct fuel-air ratio in place of slightly rich fuel-air ratio (6%) as in case of T_3 .
- ▶ However, the behaviour of T_4 with compression ratio is different from that of T_3 as shown in Fig.4.10 Unlike T_3 , the exhaust gas temperature, T_4 is lower at high compression ratios, because the increased expansion causes the gas to do more work on the piston leaving less heat to be rejected at the end of the stroke. The same effect is present in the case of air-cycle analysis also.




Fig.4.10 – Effect of fuel-air ratio on the exhaust gas temperature

4.9 Comparison of air standard and actual cycles

- ▶ The actual cycles for internal combustion engines differ from air-standard cycles in many respects. These differences are mainly due to:
 - The working substance being a mixture of air and fuel vapour or finely atomized liquid fuel in air combined with the products of combustion left from the previous cycle.
 - The change in chemical composition of the working substance.
 - The variation of specific heats with temperature.
 - The change in the composition, temperature and actual amount of fresh charge because of the residual gases.
 - The progressive combustion rather than the instantaneous combustion.
 - The heat transfer to and from the working medium.
 - The substantial exhaust blowdown loss, i.e., loss of work on the expansion stroke due to early opening of the exhaust valve.
 - Gas leakage, fluid friction etc., in actual engines.
- ▶ Most of the factors listed above tend to decrease the thermal efficiency and power output of the actual engines. On the other hand, the analysis of the cycles while taking these factors into account clearly indicates that the estimated thermal efficiencies are not very different from those of the actual cycles.

4.10 Deviation of Actual cycle from Fuel-Air cycle

- ▶ Major deviation from of actual cycle from the Fuel air cycle is due to
 - Variation in Specific heats
 - Dissociation
 - Progressive combustion
 - Incomplete combustion of fuel
 - Time loss factor
 - Heat loss factor
 - Exhaust blowdown factor

4.10.1 Time losses

- ▶ Time losses may be burning time loss and spark timings loss.

a) Burning time loss

- ▶ In theoretical cycle, the burning is assumed to be instantaneous but actually burning takes some time. The time required depends upon F:A ratio, fuel chemical structure and its ignition temperature. This also depends upon the flame velocity and the distance from the ignition point to the opposite side of combustion chamber.
- ▶ During combustion, there is always increase in volume. The time interval between the spark and complete burning of the charge is approximately 40° crank rotation.
- ▶ The effect of time required for combustion; the maximum pressure is not produced when volume is minimum (v_c) as expected. It is produced some time after TDC. Therefore, the




Fig.4.11 – Effect of time losses on p-V diagram

pressure rises from b to c as shown in Fig.4.11.

- ▶ The point 3 represents the maximum pressure if the combustion should have taken place instantly. The difference in area of actual cycle and fuel-air cycle shows the loss of power as shown in Fig.4.11. This loss of work is called burning time loss. This time loss is defined as the loss of power due to time required for mixing the fuel with air and for complete combustion.

b) Spark Timing Loss

- ▶ A definite time is required to start the burning of fuel after generating the spark in the cylinder. The effect of this, the maximum pressure is not reached at TDC and it reaches late during the expansion stroke. The time at which the burning starts is varied by varying the angle of advance (spark advance).
 - ✓ If the spark is given at T.D.C., the maximum pressure is low due to expansion of gases.
 - ✓ If the spark is advanced by 40° to start combustion at T.D.C., the combustion takes place at T.D.C. But the heat loss and the exhaust loss may be higher and again work obtained is not optimum.
- ▶ In the above two cases, the work area is less, and, therefore, power developed per cycle and efficiency are lower.




Fig.4.12 – Effects of angle of advance α on $p - v$ diagram

- ▶ Thus for getting maximum work output, a moderate spark advance of 15° to 25° is the best.

c) Incomplete Combustion Loss

- ▶ The time loss always includes a loss due to incomplete combustion. It is impossible to obtain perfect homogeneous air-fuel mixture. Fuel vapour, air, and residual gas is present in the cylinder before ignition takes place. Under these circumstances it is possible to have excess oxygen in one part of the cylinder and excess fuel in another part of it. Therefore, some fuel does not burn or burns partially. Both CO and O₂ will appear in the exhaust.
- ▶ It should be noted that it is necessary to use a lean mixture to eliminate fuel wastage while a rich mixture is required to utilize all the oxygen. Slightly leaner mixture will give maximum efficiency but too lean a mixture will burn slowly, increasing the losses or will not burn at all causing total waste. In the rich mixture some of the fuel will not get oxygen and will be completely wasted. Also, the flame speed in the rich mixture is low, thereby increasing the time losses and lowering the efficiency.

4.10.2 Direct heat loss

- ▶ During the combustion process and expansion process, the gases inside the engine cylinder are at a considerably higher temperature, so the heat is lost to the jacket cooling water or air. Some heat is lost to the lubricating oil where splash lubrication system is used for lubricating cylinder and piston.

- ▶ The loss of heat which takes place during combustion has the maximum effect, while that lost before the end of the expansion stroke has little effect, since it can do very small amount of useful work.
- ▶ During combustion and expansion, about 15% of the total heat is lost. Out of this, however, much is lost too late in the cycle to have done any useful work.
- ▶ In case all heat loss is recovered, about 20 percent of it may appear as useful work.

4.10.3 Exhaust blowdown loss

- ▶ At the end of exhaust stroke, the cylinder pressure is about 7 bar. If the exhaust valve is opened at B.D.C., the piston has to do work against high cylinder pressure costing part of the exhaust stroke. When the exhaust valve is opened too early entire part of the expansion stroke is lost.
- ▶ Thus, best compromise is that exhaust valve be opened 40° to 70° before B.D.C., thereby, reducing the cylinder pressure to halfway to atmosphere before the start of the exhaust stroke.




Fig.4.13 – Effect of blow down